# How to login to DIR-868L router menu and change to admin password after update to Firmware 1.09SHC? (Starhub Firmware)

Note: Please ensure that you have the router wireless password which is on **the sticker label** at the base of the device.

Step 1: Open an Internet browser (such as Internet Explorer or FireFox) and enter http://192.168.0.1 into the address bar.

Step 2: The default username is Admin and the password is the same as the router wireless password entered. Click **Login**.

Step 3: Click the Tools tab at the top of the page and then click Admin from the menu on the left-hand side.

Step 4: To change the Administrator password, enter a new password in the **Password** field. Verify the password again in the **Verify Password** field.

Step 5: Click **Save Settings** to save the current configuration.

Note : **For user upgrading from firmware 1.03 to firmware 1.09, the router will automatically do a factory reset after successful upgrade**

Take note that all configuration will be lost after the factory reset.

--- END ---